General Wood Instructions

Sanding
The rule of sanding is “Never across the grain”.
1. Do not tear sandpaper. If you do, the ragged edges will often scratch the wood surface.
2. For flat surfaces, wrap a piece of sandpaper around a block of wood or use a store bought holder. Start with a coarse grade of paper and finish with a fine grade of paper(not included).
3. Be consistent. Do not sand one area with fine and another with coarse grade.

Staining
1. Be sure the wood surface is smooth and clean. Stains can accentuate any roughness or scratches of cross grain sanding. Wipe off any dirt or dust with a soft cloth.
2. A base coat of sealer/primer and a light sanding before applying stain will insure a uniform stain.
3. Apply stains in one direction following the wood grain. Use a soft brush or foam brush. Let the stain penetrate the wood, then wipe off excess stain with a soft cloth.
4. If stain looks too dark, dampen the cloth with water/thinner and wipe until you achieve the desired color. If stain is too light, let dry, then apply another coat of stain and wipe off.

Finishes
1. Outdoor projects may be finished with polyurethane or varnish.
These are toxic and must be used in a well ventilated area. Indoor projects may be finished with decoupage or left unfinished.

Safety First!

This Product May Contain Silicon Gel Packets.
REMOVE PRIOR TO USE!

Reindeer Item# SH17

S&S Worldwide

CALL TOLL-FREE 1-800-243-9232
or **Mail Your Order** to: S&S Worldwide
PO Box 513
Colchester, CT 06415-0513
FAX #: 1-800-566-6678
Customer Service: 1-800-937-3482
Internet home page address: http://www.sswww.com
Email address: service@sswww.com

© Copyright 2007 S&S Worldwide Inc. All rights reserved. No part of this project may be copied or duplicated without the express written permission of S&S Worldwide.

Item No. SH17 Made in China

Reindeer

PLEASE READ ALL INSTRUCTIONS BEFORE STARTING

- ✔ Precut Wooden Pieces
- ✔ Ribbon
- ✔ Jingle Bell
- ✔ Wiggly Eyes
- ✔ Pompon
- ✔ Sandpaper
- ✔ Instructions

YOU WILL NEED...

Protected Work Surface
Soft Cloth
Paint or Stain
Brushes
Glue

PREP TIME: 5 MIN

PROJECT TIME: 1 HOUR plus drying time.

WARNING:
CHOKING HAZARD - Small parts. Not intended for children under 3 years.
SUFFOCATION HAZARD - To avoid danger of suffocation, keep plastic bags away from babies and children. Do not use bags in cribs, carriages, or playpens.

S&S Worldwide

SH17

START

Product Instructions:

1. a. Sand all wooden parts until smooth. Wipe off any excess dust with a soft cloth.
   b. Stain or paint the wooden pieces. A combination of stain and paint looks nice. Let dry 30 minutes.

Refer to figure throughout assembly.

2. a. Take body part (A) and insert front and back legs (B), matching notched areas of each piece. Notice how the legs automatically angle outward for a perfect stance. They should fit snugly so there is no need for gluing.
   b. Take antlers (C) and insert notched area into notched area at top of the head.
   c. Apply a small amount of glue onto pompon and wiggly eyes and press into place as indicated in Figure A. Let dry for 25 minutes.

3. a. Take the ribbon length and fold in half length-wise.
   b. Slide the jingle bell onto ribbon length until it reaches the center of the ribbon.
   c. Place ribbon with bell attached around the deer's neck, making sure that the bell is in the front.
   d. Tie a pretty bow at the back of the neck.

FIGURE A



FINISH