GP3045

The Launcher Kit (Pk/12)

MORE IDEAS...

How far can you launch a pom pom?

Can you launch a pom pom into a cup?

MAKING IT EASY to SAVE MORE on your next order!

$10 OFF
Your Next Order of only $39.00 or more.

Please mention Offer Code: **M2467**
Minimum order $39 excludes shipping and taxes.
Limit one per order.
May not be combined with other offers or bid or contract pricing.
See current S&S® catalog or Help at ssww.com for Offer Terms and Conditions.
We reserve the right to terminate this offer at any time without notice.

Call Toll-Free
1-800-243-9232

Online:
ssww.com

Customer Service:
1-800-937-3482

Email:
cservice@ssww.com

FAX:
1-800-566-6678

S&S® Worldwide

© Copyright 2013 S&S® Worldwide Inc. All rights reserved. No part of this project may be copied or duplicated without the express written permission of S&S Worldwide.

Kit may contain silicone gel packets, which should be removed before use.

Reorder Number
GP3045 | 1.0

S&S® Worldwide
MAKING IT EASY
to Help People Play and Learn

Gee-Perz®
Just Add Imagination... We Provide the Rest!

The Launcher Kit (Pk/12)

PLEASE READ ALL INSTRUCTIONS BEFORE STARTING



YOUR KIT CONTAINS:
- MDF Launcher Parts
- Wooden Dowels Diameter
- Rubber Bands
- Markers
- Glue
- Tablecloth
- Pom Poms

YOU WILL NEED:
- A Hammer
- Flat Work Surface

AGE GROUP: 8 and up
PROJECT TIME: 45 minutes

GP3045

INSTRUCTIONS:

1. Have each person open the project bag and lay out all pieces.

2. Place one triangle down and place pegs in appropriate holes. Secure with glue (Figure A).

TIP: Use a hammer to gently tap tight-fitting pegs in place or use your hand to twist dowels into holes.

3. Refer to diagrams for rubber band placement: Place bottom end of launch piece (Figure B) into the rubber band. Run the band under the smaller peg on bottom of triangle. Wrap over the catapult. Run rubber band over the top peg of the triangle. Secure band behind top of catapult (Figure C).

4. Rubber band should resemble the letter Z.

5. Put a small dab of glue on the tips of the dowels. Align second triangle over pegs. Gently use the hammer to tap dowels into holes. Allow to dry.

6. Using the assorted markers, decorate your new Launcher Kit.

7. Try launching the pom poms by placing one in the top of the launch piece. Pull back on the top and let go!

FIG. A



FIG. B



FIG. C